



## MODEL 1005 5-BIKE PARKING RACK Owner's Manual

Content:	Qty
57.8" x 30.9" 5-Bike Grid	1
End-piece bent tubes	2
58" steel base tube	1
M10-95mm grid top boltsw/16mm nuts	2
M10-60mm bottom bolts (no nuts)	4
Plastic end caps	6


### ASSEMBLY INSTRUCTIONS:

1. Attach the side tube sections to the 57.8" pole using the bolts supplied. Once attached to the pole, the end tubes should be in upright position.

Note: You may need someone to assist you by holding the grid while connecting it to the side tubes.

2. Attach the grill section to the side tubes. Note that 60mm bottom bolts for side tubes do not need any nuts. The side-tubes are pre-threaded.

3. Tighten the bolts and insert the plastic end plugs.



### Specifications:

Heavy duty 16-gauge steel tubing  
Fully welded and galvanized  
Dimensions: 57.8" L x 26" W x 30.9" H  
Capacity: 5 full-size bicycles (single side)  
Shipping Weight: 41 Lbs  
Packing: Cardboard box  
Meets UPS/FEDEX ground shipping requirements

### LIMITED WARRANTY

Husky bicycle parking racks are warranted to be free from defects in material and workmanship for a period of five years (5-years) from date of purchase. Proof of original retail purchase is required on all warranty claims.

This warranty does not cover normal wear and tear, damage or dents, exposure to corrosive chemicals, or misuse. This warranty is limited to replacement of all or parts of the bicycle rack as sole remedy and in no event Husky or HLF Distributing, Inc. shall be liable for any incidental or consequential damages, losses, or expenses.

Please contact Husky Bicycles at (800) 392-3337 if you have any questions.