

## **CLUB 5-Function Cyclocomputer**

Operating Instructions:

### **Setting Up Your Unit**

1. Set speed scale – In speed/distance mode, press left yellow key for 6 seconds, once the screen is cleared press left key once to change from km/h to m/h. Press right key to save.
2. Setting Clock – Press right and left key at the same time in Speed/Time mode. Use left key to change hour when hour number is blinking. Use right key to save and move to minute number, then use the left key to change minutes. Press right key to save.
3. Change/Clear Odometer – Follow the instructions in (1) above, press right key to move to odometer and use left key to make changes. Use right key to move to next digit and save previous digit.
4. Calibrating – Setting Wheel Diameter – In speed/distance mode, press left key for 6 seconds until the screen clears. Press right key once and calibration number begins blinking. Use left key to change calibration. Use the following chart to set the correct calibration for your unit:

<b>Bike Size</b>	<b>Calibration</b>
20"	160
24"	192
26"	208 (default value)
27"	216
700x20C	209
700x25C	211